

# MONTERINGSANVISNING för golvankare på betong. ASSEMBLY INSTRUCTIONS for floor anchor on concrete.

1. Använd ankaret (A) för att markera var de 4 hålen ska borrar. Borra 4 st  $\varnothing 16$  mm hål, minst 10 cm djupa. Borr medföljer ej.
  2. Sätt in skruven hela vägen i metallexpandern (B) och placera den sedan i borrhålet.
  3. När expandern (B) är monterad i hålet skruvar du loss skruven och lämnar kvar expandern.
  4. Placera ankaret (A) över hålen och fäst den med skruvarna du lossade i föregående steg, skruva fast hårt.
  5. Lägg en metallkula (C) i mitten av varje skruv och slå ner med hammare och metallstav. Därmed kan ingen skruva loss skruven. Metallstav medföljer ej.
  6. Banka slutligen fast varje metallock (D) över skruvarna, med den böjda sidan uppåt.
1. Use the anchor (A) to mark where to drill the 4 holes. Drill the 4  $\varnothing 16$  mm holes, with a minimum depth of 10 cm. Drill is not included.
  2. Insert the screw all the way into the metal expander (B) and then place it in the hole.
  3. When the expander (B) is mounted in the hole, unscrew the screw and leave the expander.
  4. Place the anchor (A) over the holes and secure it with the screws you loosened in the previous step, fasten tight.
  5. To protect the screws, attach a metal ball (C) to the center of each screw and strike with a hammer and metal rod. Metal rod is not included.
  6. Finally, secure each metal cover (D) over the screws, with the curved side facing up.

