



Spare parts for 26201-0085

ITEM NO	PARTS NAME	PARTS NO	Artnr
101	ANVIL	1230D-0330001-1	-
101A	ANVIL KIT,101+105+106	12227-0330003-1	26201-6108
102	HAMMER PIN	1230B-0320001-1	26201-7023
103	HAMMER FRAME	1230E-0320001-1	26201-7049
104	HAMMER	1230C-0320001-1	26201-7056
105	SOCKET RETAINER	2040306-00031-0	-
106	O - RING	2041109-01240-0	-
201	HOUSING	12201-032F701-1	(26201-7064)
202	HAMMER CASE BUSHING	1230K-0320005-1	(26201-7072)
203	PACKING	12341-0320001-1	26201-7080
204	REAR COVER	12394-032A102-1	(26201-7098)
205	HEX.SOC.HD.BOLT	2040101-03060-2	(26201-7106)
206	SPRING RETAINER	12381-0200001-1	(26201-7114)
301	BEARING	2041200-00121-0	-
301A	BEARING KIT 301+307	301+307 IJ238-B1	26201-7122
302	FRONT BEARING PLATE	12312-0070012-1	(26201-7130)
303	BLADES	12314-0070012-1	26201-7148
304	ROTOR	12313-0070014-3	26201-7155
305	CYLINDER	12315-0070023-1	(26201-7163)
306	REAR END PLATE	12316-0070009-1	(26201-7171)
307	BEARING	2041200-00111-0	-
308	SPRING PIN	2040400-05040-0	26201-7197
309	SPRING PIN	2040400-05060-0	26201-7205

401	TRIGGER UNIT	12225-0321901-1	(26201-7213)
402	REVERSE VALVE	1230L-0334701-1	26201-8302
403	BALL	2040800-05020-0	(20734-1165)
404	POSITIONING SPRING	1230J-0320001-1	(26201-7247)
405	O - RING	2041109-01030-0	-
405A	O - RINGKIT 405+406	405+406 IJ238-B1	(26201-7254)
406	O - RING	2041105-01010-0	-
407	SPRING A	1230L-0321901-1	(26201-7262)
408	FLAT HD.SCREW	2040103-01010-0	(26201-7270)
409	SPRING PIN	2040400-02100-0	26201-9003
410	SEAL BUSHING	1230K-0074705-1	-
410A	AIR INLET KIT 410+411+412+413	410-413 IJ238-B1	26207-7304
411	SEAL	12319-0070006-1	-
412	TIP VALVE	12226-0071101-1	-
413	SPRING	12308-0150001-1	-
414	DEFLECTOR	12346-0134702-1	(26201-7312)
415	AIR INLET	12309-0074709-1	(20774-2586)
418	AIR INLET	12309-0074713-1	(20774-2594)
419	O - RING	2041102-02010-0	(26201-7338)
420	EX-CONCENTRIC RING	2040304-48010-0	20774-2560